SKU # 230 469

Model # TY-S46-C

USE AND CARE GUIDE

Set of 2 Lighted Spiral Tree



THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this Set of 2 Lighted Spiral Tree. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

Guarantee

What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

1-877-527-0313

HOMEACCENTSHOLIDAY.COM

Pre-Assembly

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return to store. Assembly of this product may require more than one person.

PACKAGE CONTENTS



Package Contents/Parts List		
Part	Description	Quantity
A	Spiral Tree	1
B	Tree Stand Center Cone	1
C	Stake Section	1
D	Pole Section	3
E	Tree Stand Leg	4
F	Star Tree Topper	1

Package Contents/Parts List		
Part	Description	Quantity
G	Driving Cap	1
H	Center Cone	1
I	Ground Stake	4
J	Fuse	1
K	Replacement Bulbs	5

Assembly

Assembling the Spiral Tree

FIG.1





FIG.2

FIG.3



FIG.4



For Indoor Use:

(1) Slide the Four Legs (E) into the matching slots on the sides of the Tree Stand Center Cone to create the Tree Stand (B). FIG.1
(2) Insert a Pole Section (D), with the big end down, into the Tree Stand. FIG.2
(3) Attach the remaining two Pole Sections. FIG.2
(4) Insert the top Pole Sections tapered end through the top of the tree and fit the end inside the bottom of the center cone (H) in the tree. FIG.3
(5) Place the Star Tree Topper (F) on the top of the Spiral Tree by inserting into the top of Center Cone. FIG.3
(6) Secure the Spiral Tree to the Tree Stand by attaching the four strings to each of the legs.FIG.4
(7) Plug in the Spiral Tree. FIG.4

For Outdoor Use:

(1) Attach the Driving Cap (G) to the top of the Stake Section (C).
(2) Push or drive the Stake Section into the ground. Remove the Driving Cap after the Stake Section is firmly in the ground. FIG.5
(3) See Steps 2-5 from Indoor Use above for Spiral Tree Assembly.
(4) Secure the Spiral tree to the ground by tying the strings to the Ground Stakes (I) and firmly push the Ground Stakes into the ground.
(5) Adjust the four Strings/Ground Stakes so the Spiral Tree is positioned evenly. FIG.5
(6) Plug in the Spiral Tree.

FIG.5



Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 61.2 Watts (0.51Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
b. Wipe the unit with a damp cloth and allow the unit to dry before storing.
c. Store the product neatly in a cool, dry location protected from sunlight.

FOR INDOOR AND OUTDOOR USE